


การตั้งค่าการใช้งาน Wireless

1. เปิด Browser พิมพ์ **192.168.1.1** ในช่อง Address แล้วกด Enter



2. ใส่ Username : **admin** และ Password : **aisadmin** แล้วกด Login



3. หลังจาก Login แล้ว จะเข้าสู่หน้า Home

Logout

	State	Network	Security	Application	Management																						
Device Information	State » Device Information » Device Information																										
Device Information	On this page, you can query device information.																										
Wireless State	<table border="1"> <thead> <tr> <th colspan="2">Device Information</th> </tr> </thead> <tbody> <tr> <td>Software Version</td> <td>RP2570</td> </tr> <tr> <td>Hardware Version</td> <td>WKE2.134.285D2G</td> </tr> <tr> <td>Device Model</td> <td>AN5506-04-D2G</td> </tr> <tr> <td>Device Description</td> <td>GPON</td> </tr> <tr> <td>ONU State</td> <td>O1(STATE_INIT)</td> </tr> <tr> <td>ONU Regist State</td> <td>INIT</td> </tr> <tr> <td>LOID</td> <td>fiberhome</td> </tr> <tr> <td>CPU Usage</td> <td>4%</td> </tr> <tr> <td>Memory Usage</td> <td>56%</td> </tr> <tr> <td>Web Server port</td> <td>80</td> </tr> </tbody> </table>					Device Information		Software Version	RP2570	Hardware Version	WKE2.134.285D2G	Device Model	AN5506-04-D2G	Device Description	GPON	ONU State	O1(STATE_INIT)	ONU Regist State	INIT	LOID	fiberhome	CPU Usage	4%	Memory Usage	56%	Web Server port	80
Device Information																											
Software Version	RP2570																										
Hardware Version	WKE2.134.285D2G																										
Device Model	AN5506-04-D2G																										
Device Description	GPON																										
ONU State	O1(STATE_INIT)																										
ONU Regist State	INIT																										
LOID	fiberhome																										
CPU Usage	4%																										
Memory Usage	56%																										
Web Server port	80																										
Wan State																											
Lan State																											
Optical Power																											

การตั้งค่า SSID name

1. เลือก **Network -> Wlan Settings -> Advanced**
2. ในช่อง **SSID Name** ให้ผู้ใช้กำหนด SSID name
3. ในช่อง **Pass Phrase** ให้ผู้ใช้กำหนดรหัสผ่าน
4. กด **Apply** เพื่อบันทึกการเปลี่ยนแปลง

Logout

StateNetworkSecurityApplicationManagement

Wlan Settings

BasicAdvancedWIFI Control

LAN Settings

BroadBand Settings

DHCP Server

Remote Management

Authentication

IPV6

Network » Wlan Settings » Advanced

Setup the wireless security and encryption to prevent from unauthorized access and monitoring.

Select SSID

SSID Choice1EnableDisable

SSID Name

SSID NameFiberhomeONU 2.4G*(1-32 Characters)Hidden

Security Policy

Security ModeWPAPSKWPA2PSK

WPA(Wi-Fi Protected Access)

WPA AlgorithmsTKIPAESTKIPAES

Pass Phrase12345678*(You can input 8-64 characters)

ApplyCancel