

วิธีดูค่า Status ที่บ่งบอกถึง Performance ของ Internet

1. เปิด Browser พิมพ์ **192.168.1.1** แล้วกด Enter



2. ใส่ Username: **admin** และ Password: **aisadmin** จากนั้นกด Login




Enter the username and password for FiberHome router.

Username:

Password:

3. หลังจาก Login สำเร็จ จะเข้าสู่หน้าจอ ดังภาพด้านล่าง



4. เลือก Status -> Network



HG180Ev2 Dual Band 802.11ac WiFi Router

Home

Status

Device Information

WAN

Network

Ethernet

LAN

Statistics

ARP

VoIP

WiFi Neighbor

Basic Setup

Advanced Setup

Applications

Management

IPv4 WAN Connection Status

Connection Name	Type	IP Address/Mask	Default Gateway	Primary DNS	Secondary DNS	Status
ETH_2_1_1_INTERNET_B_IP	IP_Bridged	/				Connected
aisfibre_ipv6_ipv4_pppoe	PPPoE	100.102.153.23/255.255.255.255	100.102.0.1	115.178.58.10	115.178.58.26	Connected
ETH_2_2_1_OTHER_B_IP_VID_30	IP_Bridged	/				Connected

IPv6 WAN Connection Status

Connection Name	Type	IP Address	Default Gateway	Primary DNS	Secondary DNS	Prefix	Status
aisfibre_ipv6_ipv4_pppoe	PPPoE						Disconnected

DS-Lite Status

Connection Name	Type	Mode	AFTR Address	Status
ETH_2_1_1_INTERNET_B_IP	DHCP	Auto		Disconnected
aisfibre_ipv6_ipv4_pppoe	PPPoE	Auto		Disconnected

[Refresh](#)