

การตั้งค่าการใช้งาน Wireless

1. เปิด Browser พิมพ์ **192.168.1.1** แล้วกด Enter



2. ใส่ Username: **admin** และ Password: **aisadmin** จากนั้นกด Login




Enter the username and password for FiberHome router.

Username:

Password:

3. หลังจาก Login สำเร็จ จะเข้าสู่หน้าจอดังภาพด้านล่าง



เนื่องจาก HG180Ev2 เป็น Router รูปแบบ Dual-band สามารถกระจายสัญญาณได้ทั้งความถี่ 2.4 GHz และ 5 GHz จึงต้องมีการตั้งค่า Configuration ทั้งสำหรับความถี่ 2.4 GHz และสำหรับความถี่ 5 GHz

การตั้งค่า SSID name สำหรับ Wireless 2.4 GHz

1. เลือก **Basic Setup** -> **WLAN** -> **Basic configuration 2.4 GHz**
2. ในช่อง **SSID** ให้ผู้ใช้กำหนด SSID name
3. กด **Apply** เพื่อบันทึกการเปลี่ยนแปลง



The screenshot shows the web interface of the AIS Fibre HG180Ev2 Dual Band 802.11ac WiFi Router. The left sidebar contains a navigation menu with options: Home, Status, Basic Setup (selected), LAN, WLAN, Basic Configuration 2.4GHz (highlighted), Basic Configuration 5GHz, Security Setting 2.4GHz, Security Setting 5GHz, Advanced Setup, Applications, and Management. The main content area is titled 'WLAN Basic Configuration 2.4GHz'. It includes several settings: 'Enable WLAN' (checked), 'Choose SSID' (dropdown menu showing 'SSID1'), 'Enable SSID' (checked), 'Enable Isolation' (unchecked), 'Hide SSID' (unchecked), 'SSID' (text field containing 'aisfibre_2.4G_F70058', highlighted with a red box), 'BSSID' (text field containing '10:58:87:F7:00:5A'), and 'Country' (dropdown menu showing 'THAILAND'). At the bottom are 'Apply' and 'Refresh' buttons.

การตั้งค่า SSID Password สำหรับ Wireless 2.4 GHz

1. เลือก **Basic Setup** -> **WLAN** -> **Security Setting 2.4 GHz**
2. ในช่อง **WPA Preshare key** ให้ผู้ใช้กำหนด SSID password
3. กด **Apply** เพื่อบันทึกการเปลี่ยนแปลง



The screenshot shows the web interface of the AIS Fibre HG180Ev2 Dual Band 802.11ac WiFi Router, specifically the 'WLAN Security Setting 2.4GHz' page. The left sidebar is the same as the previous screenshot, but 'Security Setting 2.4GHz' is now highlighted. The main content area is titled 'WLAN Security Setting 2.4GHz'. It includes settings: 'Choose SSID' (dropdown menu showing 'SSID1'), 'Authentication' (dropdown menu showing 'WPA-PSK/WPA2-PSK MIXED'), 'Group Key Update' (text field containing '1800'), 'Timer' (text field), 'WPA Preshare key' (text field containing '*****', highlighted with a red box), and 'Encryption Mode' (dropdown menu showing 'AES'). A link 'Click here to display' is next to the WPA Preshare key field. At the bottom are 'Apply' and 'Refresh' buttons.

การตั้งค่า SSID name สำหรับ Wireless 5 GHz

1. เลือก **Basic Setup** -> **WLAN** -> **Basic configuration 5 GHz**
2. ในช่อง **SSID** ให้ผู้ใช้กำหนด SSID name
3. กด **Apply** เพื่อบันทึกการเปลี่ยนแปลง



The screenshot shows the web interface of the AIS Fibre HG180Ev2 Dual Band 802.11ac WiFi Router. The left sidebar contains a navigation menu with options: Home, Status, Basic Setup (selected), LAN, WLAN, Basic Configuration 2.4GHz, Basic Configuration 5GHz (highlighted), Security Setting 2.4GHz, Security Setting 5GHz, Advanced Setup, Applications, and Management. The main content area is titled 'WLAN Basic Configuration 5GHz'. It includes several settings: 'Enable WLAN' (checked), 'Choose SSID' (SSID5), 'Enable SSID' (checked), 'Enable Isolation' (unchecked), 'Hide SSID' (unchecked), 'SSID' (aisfibre_5G_F70058, highlighted with a red box), 'BSSID' (10:58:87:F7:00:5B), and 'Country' (THAILAND). At the bottom are 'Apply' and 'Refresh' buttons.

การตั้งค่า SSID Password สำหรับ Wireless 5 GHz

1. เลือก **Basic Setup** -> **WLAN** -> **Security Setting 5 GHz**
2. ในช่อง **WPA Preshare key** ให้ผู้ใช้กำหนด SSID password
3. กด **Apply** เพื่อบันทึกการเปลี่ยนแปลง



The screenshot shows the web interface of the AIS Fibre HG180Ev2 Dual Band 802.11ac WiFi Router, specifically the 'WLAN Security Setting 5GHz' page. The left sidebar is identical to the previous screenshot, with 'Security Setting 5GHz' highlighted under the WLAN section. The main content area includes settings for 'Choose SSID' (SSID5), 'Authentication' (WPA-PSK/WPA2-PSK MIXED), 'Group Key Update' (1800), 'Timer' (1800), 'WPA Preshare key' (displayed as dots, highlighted with a red box), and 'Encryption Mode' (AES). A link 'Click here to display' is next to the WPA Preshare key field. At the bottom are 'Apply' and 'Refresh' buttons.