

การ Restore to Default

ผู้ใช้สามารถทำการ Restore to Default ได้ 2 วิธี คือ แบบ Hardware และแบบ Software โดยทั้งสองวิธีให้ผลการทำงานในแบบเดียวกัน

แบบ Hardware

1. กดปุ่ม **Reset** ค้างไว้ประมาณ 10 วินาที

แบบ Software


1. เปิด Browser พิมพ์ **192.168.1.1** ในช่อง Address แล้วกด **Enter**



2. ใส่ Username: **admin** และ Password: **aisadmin** แล้วกด **Login**



3. จากแถบเมนูด้านบน เลือก **System Tools**
4. จากแถบเมนูย่อยด้านซ้าย เลือก **Restore Default Configuration**
5. กดปุ่ม **Default** เพื่อเริ่มการ Restore to Default



The screenshot shows the Huawei HG8245H web management interface. At the top, there is a header with the Huawei logo, the model number 'HG8245H', and a 'Logout' link. Below the header is a navigation bar with tabs for Status, WAN, LAN, IPv6, WLAN, Security, Route, Forward Rules, Network Application, Voice, and System Tools. The 'System Tools' tab is selected. On the left side, there is a sidebar menu with various system tools, including 'Restore Default Configuration', which is highlighted. The main content area displays the 'System Tools > Restore Default Configuration' page. It features a yellow box with the text 'On this page, you can restore the default settings.' and a red-bordered button labeled 'Default'.

Reboot
Configuration File
Firmware Upgrade
Restore Default Configuration
Maintenance
VoIP Statistics
VoIP Diagnose
Remote Mirror
User Log
Debug Log
Firewall Log
ONT Authentication
Time Setting
TR-069
Advanced Power Management
Modify Login Password
Fault Info Collect
Indicator Status Management
SSL Certificate Management
Open Source Software Notice

System Tools > Restore Default Configuration

On this page, you can restore the default settings.

Default

Copyright © Huawei Technologies Co., Ltd. 2009-2015. All rights reserved.