

การ Restore to Default

ผู้ใช้สามารถทำการ Restore to Default ได้ 2 วิธี คือ แบบ Hardware และแบบ Software โดยทั้งสองวิธีให้ผลการทำงานในแบบเดียวกัน

แบบ Hardware


- กดปุ่ม **Reset** ค้างไว้ประมาณ 10 วินาที

แบบ Software


- เปิด Browser พิมพ์ **192.168.1.1** ในช่อง Address แล้วกด **Enter**




- ใส่ Username: **admin** และ Password: **aisadmin** แล้วกด **Login**



- เข้าสู่หน้าจอ setup



4. จากแถบเมนูด้านซ้าย เลือก **Administration** -> **System Management**
5. กด **Restore Default** เพื่อเริ่มดำเนินการ



The screenshot shows the ZTE F660 web interface. The left sidebar contains a menu with the following items: +Status, +Network, +Security, +Application, -Administration (highlighted), +TR-069, +User Management, Login Timeout, -System Management (highlighted), System Management (highlighted), Software Upgrade, User Configuration Management, Default Configuration Management, Remote Upgrade, USB Backup, USB Restore, Log Management, +Diagnosis, +Loopback Detection, IPv6 Switch, VoIP Protocol Switch, 3G Basic Configuration, and +Help. The main content area shows the path: Administration-System Management-System Management. It includes a 'Reboot' button and a 'Restore Default' button, which is highlighted with a red box. The 'Restore Default' button is accompanied by a warning icon and text: 'Click this button to restore the configuration to factory default settings. The device will reboot after operating.'

©2008-2015 ZTE Corporation. All rights reserved.